


# SLOT COVER




Easily attached or removed Prevent incorrect PCB slot insertions

Do you have these kind of Problems in storing the PCB board while using Magazine Rack?





Have you ever accidentally damaged the parts or dropped the board due to incorrect insertions?




### Groove setting is selectable. Flexible solutions to different customer processes

#### Parts structure







SCS-NWH-A

**1** Attaching rod

Quantity:1

②Stopper [with claw] ③Stopper [without claw]


SCB-500 SCS-CBL-A


(stainless steel made) (antistatic POM made) (antistatic POM made) Quantity:10pcs/bag Quantity:50pcs/bag


## **Assembling method**

- 1. 50 available stopper slots per rod to customize to your Magazine Rack pitch.
- 2. Set the stopper [with claw ] on the upper and lower hole of the rod.
- 3. Put the stopper [without claw] into slots as your needs.


#### Fixing method in Magazine Rack







2. Hook the claw and push inside to the Magazine Rack



3. Installation completed. Remove by simply pushing to the outside.

Applicable Nikko-Rack of NIX		Standard specification	4C specification
Nikko- Rack (M size)	R25 series (R,N,SR25)		
	NKAJ-0525R series (0525R,N,SR)		△ (unavailable on Fixed side )
	NKAJ-0525R3 series (0525R3,N3,SR3)		△ (unavailable on Fixed side )



# Rubröder GmbH Factory Automation

Theodor-Neizert-Str. 1, 56170 Bendorf, Germany

Tel.: 0049 (0) 2622-943730

Email: info@rubroeder.de; www.rubroeder.com



